

# Addendum

DATE: April 5, 2018  
TO: Bidders  
FROM: Cathy Wright, Purchasing Assistant  
RE: **Addendum #3** – Bid#810606-Summerwind Elementary Exterior  
Paint/Seal

---

**ITEM 1: Specifications**

All CMU is to be sealed. Attached is the pre-approved manufacturer and their specifications.

**ACKNOWLEDGE RECEIPT OF THIS ADDENDUM (NO. 3) ON THE QUOTE SUBMISSION FORM AND INCLUDE IT WITH YOUR QUOTE.**



To Whom It May Concern:

RE: West Ada School District

Thank you for choosing PROSOCO's Blok-Guard<sup>®</sup> Graffiti Control II for use on your project. Pertaining to the application of this product, instructions are included in this document. Additional information can be found on Product Data Sheets on in Product Specifications.

**Application**

Before applying, read "Preparation" and "Safety Information" sections in the Manufacturer's Product Data Sheet for Weather Seal Blok-Guard<sup>®</sup> & Graffiti Control II. Refer to the Product Data Sheet for additional information about application of Blok-Guard<sup>®</sup> & Graffiti Control II. Do not dilute or alter.

For best results, apply Blok-Guard<sup>®</sup> & Graffiti Control II "wet-on-wet" to a visibly dry and absorbent surface.

**Spray**

1. Using low-pressure (<50 psi) spray equipment, saturate, "wet-on-wet" spraying from the bottom up. Avoid excessive overlapping.  
*For textured and porous surfaces, apply enough material to create 6 to 8 inch rundown below the contact point.*
2. Let first application penetrate masonry surface for 2 to 3 minutes.  
*For textured and porous surfaces, reapply in same saturating manner to ensure complete coverage of recessed surfaces.*
3. Immediately brush out runs and drips to prevent build up.

**Brush or Roller**

Saturate uniformly. Let product penetrate for 2-3 minutes. Re-saturate. Brush out heavy runs and drips that don't penetrate.

**Fluted architectural block:**

Saturate from the bottom up. Spray in an "overlapping X pattern" for complete coverage of recessed surfaces. Let the first application penetrate for 2-3 minutes. Re-saturate. Less will be needed for the second application.

**Dense, Smooth Surface Application Instructions**

Apply enough in a single saturating application to completely wet the surface without creating drips, puddles or rundown. Brush out or back roll all runs and drips for uniform appearance. Do not over apply. Over application may cause unacceptable color change. One application is normally enough. Always test for application rate.

**Second Coat/Porous Surface Application Instructions**

Some surfaces will need an additional coat for maximum protection. Apply the second wet-on-wet coat as soon as the first application is dry to the touch or within one hour. Allowing more than one hour between coats could reduce the effectiveness of the second coat or cause darkening. Immediately back roll or brush out runs and drips for a uniform appearance and to prevent build up.



**Drying Time:** Treated surfaces dry to the touch in 1 hour. Protect surfaces from rainfall for 6 hours following treatment. Blok-Guard® & Graffiti Control II treatments gain water repellency properties in 24 hours.

**Graffiti Removal**

Remove most types of graffiti with Defacer Eraser® Graffiti Wipe or Enviro Klean® SafStrip.

**Cleanup**

Cleanup tools, equipment and over spray with soap and warm water. Cleanup is more difficult from surfaces hotter than 95 degrees F (35 degrees C).

Should you require additional information not contained in this document or have questions please contact your local PROSOCO Manufacturer's representative or myself.

Berny Breinholt

3.7.9 Product Solutions

301-577-4769

Berny.379@gmail.com

Best regards,

Brent Morris

Regional Sales Manager

303-912-5545